

There are five different shaped parts for this hood; there are two of each shape except for part #1 (the center part). Each numbered part will overlap the preceding part and the two parts will get screwed together. Please see that all bends and tabs go toward the inside.

**Assembly Steps:**

1. Stand part #1 on end.
2. Find the arrow on part #2. The arrow points to section that overlaps part #1. Attach part #2 to the left and right side of part #1 (center piece).
3. Overlap and attach part #3 to part #2 on both the left and the right side (bends face in).
4. Part #4 attaches to one end overlapping all tabs.
5. Part #5 attaches to the opposite side.
6. To attach hooks place washer on the inside. Place one nut on the inside of the hood and one on the outside, turn them toward each other to lock hook into place.
7. Insert tapered collar into part #5 and bend tabs, then slide duct over the collar.
8. Insert the second tapered collar to your exhaust point. Then connect the fan to the collar and the duct to the other side of the fan.
9. use tape to seal up all the duct connections.

